



akYtec ALP

Programming software for programmable relays akYtec

User manual

Contents

1	About software	4
1.1	General.....	4
1.2	System requirements	4
2	Abbreviations and terms	5
3	Interface description	6
3.1	Overview	6
3.2	Menu	6
3.3	Toolbars	8
3.4	Workspace	9
3.5	Library Box	10
3.6	Property Box.....	11
3.7	Display Manager	12
3.8	Status bar	12
4	Basics	14
4.1	Program execution	14
4.2	Project creation	14
4.3	Connection to device.....	15
4.4	Upload project to device.....	16
4.5	Firmware update	16
4.6	Firmware restoration	16
5	Device information	17
6	Device configuration	18
6.1	Display.....	18
6.2	Clock	18
6.3	Interfaces.....	19
6.3.1	Add / remove interface.....	19
6.3.2	RS485 Interface configuration	20
6.3.2.1	<i>Master mode</i>	21
6.3.2.2	<i>Slave mode</i>	24
6.4	Inputs.....	25
7	Variables	27
7.1	Properties	27
7.2	Data type	27
7.3	Standard variables	28
7.4	Service variables	29
7.5	Network variables.....	29
8	Circuit program development	31
8.1	Using of library elements.....	31
8.2	Using of variables.....	31

8.3	Using of constants.....	32
8.4	Reading / writing for function blocks	33
8.5	Using of feedbacks.....	33
8.6	Using of comments.....	34
8.7	Arrange elements.....	35
8.8	Execution sequence	35
8.9	Network data exchange	36
8.10	Simulation mode	37
9	Display programming	39
9.1	Display form structure	39
9.2	Display properties.....	40
9.3	Display editor.....	41
10	Library	43
10.1	Functions	43
10.1.1	Logical operators	43
10.1.1.1	Conjunction (AND).....	43
10.1.1.2	Disjunction (OR)	44
10.1.1.3	Negation (NOT)	44
10.1.1.4	Exclusive OR (XOR).....	44
10.1.2	Mathematical operators	45
10.1.2.1	Addition (ADD, fADD)	45
10.1.2.2	Subtraction (SUB, fSUB)	45
10.1.2.3	Multiplication (MUL, fMUL)	46
10.1.2.4	Division (DIV, fDIV).....	46
10.1.2.5	Modulo operation (MOD)	46
10.1.2.6	REAL-Power function (fPOW)	47
10.1.2.7	REAL-Absolute function (fABS).....	47
10.1.3	Relational operators.....	47
10.1.3.1	Equal (EQ).....	47
10.1.3.2	Greater than (GT, fGT)	48
10.1.3.3	Binary selection (SEL)	49
10.1.4	Bitshift operators	49
10.1.4.1	Shift register left (SHL)	49
10.1.4.2	Shift register right (SHR).....	50
10.1.5	Bit operators.....	50
10.1.5.1	Read single bit (EXTRACT).....	50
10.1.5.2	Set single bit (PUTBIT).....	51
10.1.5.3	Decoder (DC32).....	51
10.1.5.4	Encoder (CD32).....	52
10.2	Function blocks.....	52
10.2.1	Triggers.....	52

10.2.1.1	<i>RS trigger reset dominant (RS)</i>	52
10.2.1.2	<i>SR trigger set dominant (SR)</i>	53
10.2.1.3	<i>Rising edge (RTRIG)</i>	53
10.2.1.4	<i>Falling edge (FTRIG)</i>	53
10.2.1.5	<i>D-trigger (DTRIG)</i>	54
10.2.2	Timers	54
10.2.2.1	<i>Pulse (TP)</i>	54
10.2.2.2	<i>ON-delay timer (TON)</i>	55
10.2.2.3	<i>OFF-delay timer (TOF)</i>	55
10.2.2.4	<i>Timer (CLOCK)</i>	56
10.2.2.5	<i>Week timer (CLOCKW)</i>	57
10.2.3	Generators	57
10.2.3.1	<i>Pulse generator (BLINK)</i>	57
10.2.4	Counters.....	58
10.2.4.1	<i>Threshold counter with self-reset (CT)</i>	58
10.2.4.2	<i>Universal counter (CTN)</i>	59
10.2.4.3	<i>Threshold counter (CTU)</i>	59
10.2.5	Controllers.....	60
10.2.5.1	<i>PID controller (PID)</i>	60
10.3	Project macros.....	62
10.3.1	New macro	62
10.3.2	Export of macro.....	64
10.3.3	Import of macro.....	65
10.3.4	Online Macro Database	65
11	Display elements	66
11.1	Text box	66
11.2	I/O box (INT/REAL).....	67
11.3	I/O box (BOOL).....	68
11.4	Dynamic box	69
11.5	ComboBox	69
12	Calibration	71
12.1	Input calibration	71
12.2	Output calibration.....	71
13	Program examples	73
13.1	Task 1: Light switch with automatic switch-off.....	73
13.2	Task 2: Mixer control	75

1 About software

1.1 General

akYtec ALP is a programming software intended for creation of operation algorithm for programmable relays PR series produced by akYtec GmbH using the graphical language FBD (Function block diagram). With this software you can also test, modify and save your circuit program.

The project contains the circuit program and the device configuration including RS485 interfaces. Macros (user function blocks) can be created on separate workspaces. If the target device has a display, the display can be programmed using display forms that can be also created on separate workspaces. Only one project at a time can be opened.

To program the device proceed as follows:

1. Install akYtec ALP programming software on a PC
2. Start akYtec ALP
3. Select the device and create a new project or open an existing project
4. Save the project to the PC
5. Debug the project in the simulation mode
6. Load the project to a programmable relay

1.2 System requirements

akYtec ALP software runs on Windows XP/Vista/7/8/10. Pre-installed .NET Framework 2.0 software is required (if not installed, the request for its installation appears automatically).

Minimum technical requirements for the PC:

- Processor Pentium 2 and higher
- RAM 64 MB or more
- Minimum free hard disk space 30 Mb
- USB port
- Keyboard and mouse
- Monitor with minimum resolution 800x600 pixels

2 Abbreviations and terms

Abbreviations and terms used in this manual:

Table 2.1

Abbreviations and terms	Explanation
akYtec ALP	Programming software
PR	Programmable relay
FBD	Function Block Diagram is a graphical programming language
Project	An application created by the user with akYtec ALP software
Function	A structural unit of a program with one return value. The function does not store information about its internal state, i.e. if the function is called with the same input values, it will return the same output value.
Function block	A structural unit of a program with internal memory and one or more output values. Many instances (copies) of a function block can be created.
Macro	A function block created by the user
Workspace	A field for placing graphical components of a program and links between them
Program cycle	The execution time of the circuit program which depends on its complexity

3 Interface description

akYtec ALP starts with the empty user interface (see Fig. 3.1).

3.1 Overview




Fig. 3.1

1. Title bar – shows the name of the software and the path to the open project file
2. Menu bar – consists of five groups: File, View, Device, Service and Help
3. Toolbars – Standard, Service and Insert: quick access to the essential functions of ALP
4. Library Box – the panel shows the collection of functions, function blocks and macros available for the current project
5. Property Box – the panel shows the properties of the selected project element
6. Workspace – a field in the user interface to create a circuit program or a display form (shown if a project is open)
7. Status bar – shows the status of the program and the connected PR
8. Display Manager – the programming tool to control the displayed information if the target device has a display

3.2 Menu

Table 3.1 Menu "File"

New project	Open a new project. The current project will be closed.
Open project	Open a previously saved project
Save current workspace	Save the currently opened workspace
Save project	Save the current project
Save project as...	Make a copy of the project in a different folder or with a different name
Create macro...	Open the new macro in the separate workspace

Interface description

Save as a new macro	Give a name for the current macro and save it in the project
Import macro	Import a macro from a file into the project library
Export macro	Save the current macro as a file
Online Macro Database...	Open Online Macro Database
Print...	Open the dialog to set the print options for the current workspace
Recent projects	List of recently opened projects
Exit	Close akYtec ALP




Fig. 3.2 Menu "File"




Fig. 3.3 Menu "View"

Table 3.2 Menu "View"

Undo	Undo the last action
Redo	Redo the last undone action
Style	Select the color design of the window
Status indicators	Add the indicators to the status bar or remove them
Library Box	Show or hide the Library Box
Property Box	Show or hide the Property Box
Display Manager *	Show or hide the Display Manager

* Shown if PR with display is selected

Table 3.3 Menu "Device"

Transfer application to device	Upload the current project to the device memory
Firmware update...	Update the firmware of the connected device
Information...	Open the window with the information about the software, the target device and the connected device
Variables...	Open the list of the project variables
Calibration...	Start calibration
Configuration...	Open the device configuration window
Port settings...	Open the window to set the programming port options




Fig. 3.4 Menu "Device"




Fig. 3.5 Menu "Service"




Fig. 3.6 Menu "Help"

Table 3.4 Menu "Service"

Arrange elements	Function blocks of the same type will be automatically renumbered in the workspace from top to bottom and from right to left
Simulation	Start the simulation mode
Language	Select the interface language

Table 3.5 Menu "Help"

Automatic update check	If activated, the update check is performed at the start of the software
Check for updates	Open the window for software update
Version history	Open the list of software versions with descriptions in a browser
About Software	Information about the current software version

3.3 Toolbars

Table 3.6

Standard		
	New project	Open a new project. The current project will be closed.
	Open project	Open a previously saved project
	Save project	Save the current project
	Print	Open the dialog to set the print options for the current workspace
	Copy	Copy the element selected in the workspace
	Paste	Paste the copied element
	Undo	Undo the last action
	Redo	Redo the last undone action
	Transfer application to device	Upload the current project to the device memory
	Information...	Open the window with the information about the software, the target device and the connected device
	Variables	Open the list of the project variables

Interface description

Service		
	Simulation	Start the simulation mode
	Execution order	Change the execution order for the outputs or feedbacks in the circuit program or macro
	Arrange elements	Function blocks of the same type will be automatically renumbered in the workspace from top to bottom and from right to left
Insert		
	Comment field	Text field for comments
	Variable output block	Variable, which value can be set in the program
	Variable input block	Variable, which value can be read in the program
	Constant	Constant value
	Feedback	Feedback
	Network variable output block	Variable, which value can be set via network
	Network variable input block	Variable, which value can be read via network
	Block "WriteToFB"	The input value of the block is connected to one of the parameters of the selected function block and used to change it
	Block "ReadFromFB"	The output value of the block is connected to one of the parameters of the selected function block and used to read its value
	Conversion to BOOL	Conversion of any value to a Boolean value
	Conversion to INT	Conversion of any value to an Integer value
	Conversion to REAL	Conversion of any value to a Real value

3.4 Workspace

When a project is opened, the workspace with the tab **Main program** is shown in the middle part of the window (see Fig. 3.7).





Fig. 3.7 Workspace

Interface description



A circuit program can be created or modified by placing program elements and links between them in the workspace. The size of the workspace can be changed in Property Box. The inputs (left) and outputs (right) are signed as follows:

- Ix – digital inputs
- AIx – analog inputs
- Qx – relay outputs
- AOx – analog outputs
- Fx – LED indicators

The numbers (x) correspond to the numbers of physical inputs and outputs of the target device.

Inputs and outputs can be moved along the workspace up and down by drag-and-drop.

The following icons are located on the left above the workspace (see Table 3.7):

Table 3.7

	Show / hide grid	Vertical and horizontal rulers and a grid are shown in the workspace. The elements and connecting lines will be snapped to the grid.
	Zoom -	Zoom out the workspace by 10%
	Original size	Return to the original size (100%)
	Zoom +	Zoom in the workspace by 10%
	Select scale	Scale list from 20% to 400%

The icons **Split** and **Merge** are located on the right below the workspace. Use the icon **Split** to show the same circuit program in two workspaces. It can be useful if the program is too large and you want to view two different parts of the program simultaneously. Use the icon **Merge** to return to one workspace.

3.5 Library Box





Fig. 3.8 Grouped tiles

The panel **Library Box** is a component library.

The standard position of the panel **Library Box** in the window is the upper right corner (can be changed). If a project is open, the panel contains three libraries: **Functions**, **Function blocks** and **Project macros** (only the elements that can be used in the project). Select an element in the lower part of the panel to show the respective content.

View options can be changed using the icons located on the upper line of the panel.



Click the icon **Show all** to show all the elements of the selected library (see Fig. 3.9):




Fig. 3.9 Show all





Fig. 3.10 Show grouped

Click the icon  **Show grouped** to show the elements of the selected library grouped (see Fig. 3.10). Double-click the folder to open it.

For descriptions of the library groups and its elements see section 10 “Library”.

3.6 Property Box

The panel **Property Box** is used to view and modify the parameters of the program elements such as:

- Functions, function blocks, macros
- Workspace
- Inputs and outputs
- Comments, variables, constants and data type converters

Select the required element to view its properties.






Fig. 3.11

The parameters in Property Box are shown grouped by categories by default. To show them in alphabetical order click the icon . To show them grouped click the icon .

Select the input field of the parameter to edit its value.

Interface description

3.7 Display Manager




Fig. 3.12

If the target device has a display, the displayed information can be customized using Display Manager. The display can be programmed using one or more display forms with jump conditions so that the operator can switch between them to see the desired information. For further details about display programming see section 9 “Display programming”.

The tab **Display Manager** is located in the upper left corner of the window. Click the tab to open the panel. The panel contains the toolbar, the display form graphical structure and the list of the form properties.

The menu contains the following items:

Table 3.8 Display Manager toolbar

Display	
	Add display
	Delete display
	Edit
Position	
	One step up
	One step down
Zoom	
	Zoom by 10% out
	Original size
	Zoom by 10% in
	Select scale

The parameters of the selected display form are shown in the lower part of the panel. In the **Jump list** the jump conditions can be set.

Display editor

Double-click the form in the graphical structure or click the icon **Edit** to open the selected form in a separate workspace for editing.

The workspace contains a display form with icons on the right of it, which are used to change the number of the displayed rows. The rows displayed first are bold outlined.




Fig. 3.13

3.8 Status bar

The status bar contains different status indicators to show the information about the available resources of the device and the connection to the device. The indicators in the status bar may vary depending on the type of the target device.

Interface description




Fig. 3.14

The status indicator shows the used resource in percent of the total available amount. Move the mouse over the indicator to see the absolute amount of resource.

If the device is connected, the status bar contains the following information:

- **FB** – number of available and used function blocks
- **Var** – number of available and used variables

Note: If such elements as feedbacks or multiple links with common nodes are used, some variables will be created not by the user but automatically by the software.

- **Stack** – number of available and used stack levels
- **EEPROM** – available and used retain memory
- **ROM** – available and used ROM memory
- **RAM** – available and used RAM memory

Note: ALP software automatically calculates the available resources of the device and shows a warning, if the critical value is reached.

- **PRx-x.x** – type of the connected device
- **COMx** – selected port number

4 Basics

4.1 Program execution

When selecting the target device, the number of available inputs, outputs and the real-time clock availability is determined. The general structure of the programmable relay is shown in Fig. 4.1.




Fig. 4.1 PR operation flowchart

A programmable relay is a kind of PLC with a cyclically executed program:

- Step 1 – The status of physical input points is saved to the input memory cells (Input Image Table).
- Step 2 – The values from the input memory cells are read and the program is executed from its first instruction to the last one.
- Step 3 – The results are saved to the output memory cells (Output Image Table) and applied to the outputs.

When the last step is completed, the program will run again from the first step.

The time of the operating cycle depends on the complexity of the circuit program.

4.2 Project creation

To create a new project select **File > New project** in the main menu or use the equivalent icon in the taskbar. Select the target device in the dialog window **Device selection** and confirm with **OK** (see Fig. 4.2).




Fig. 4.2

When a new project is created, the workspace with an empty circuit program will appear, the status bar will be filled with the information about available resources, the panel **Li-**

Basics

Library Box shows the available program elements and the panel **Property Box** shows the workspace properties.

Circuit program

Now the main circuit program for the project can be created in the workspace in FBD language using the common program elements from the toolbar **Insert** and the specific program elements from the **Library Box**.

Display Manager

If the selected device has a display, the **Display Manager** tab will appear to the left from the workspace, where you can customize the displayed information.

Simulation

Program can be simulated only offline using the menu or toolbar **Service**. Start the simulation mode, change the state of the inputs and notice the state of the outputs to check the correctness of the program.

4.3 Connection to device

► NOTICE

The device must be powered off before connecting to PC.

The device can be connected to PC directly (PR200) or over the adapter PR-KP20 (for PR110, PR114). The required connection cables are in the package of the adapter or PR200 included.

Connect the device to a USB port of the PC, switch the power on and select the serial port in the menu **Device > Port settings**. The number of the emulated COM port can be found in the Windows Device Manager under "Connections (COM and LPT)".

If the operating system does not find the correct driver, install the driver for PR200 or for the adapter PR-KP20. It can be downloaded from akytec.de.

Select the port number in the dialog window **Port settings** and confirm with **OK**. The only setting available for the serial port is the COM port number, all other settings are fixed and displayed only for your information.

If the connection is established, the information about the connected device and the serial port is shown in the status indicators.




Fig. 4.3

Basics

4.4 Upload project to device

If the device is connected to the PC, the project can be uploaded to the device using the menu item **Device > Transfer application to device**. After the upload, the power supply can be switched off and the device can be disconnected from the PC.




Fig. 4.4

Note: After the program transfer is completed, the device goes to the operating mode and the application starts automatically.

Attention! If another application has been already stored in the memory of the connected device, it will be replaced by the new one.

4.5 Firmware update

When attempting to upload an application, you will be prompted to update the firmware, if a new version of the firmware for the connected device is available. Click **Yes** to start the update.

Ensure the safe connection between the PC and the device during the update process.

4.6 Firmware restoration





Fig. 4.5

If the device indicates firmware damage (refer to the user manual, table “Error indication”), connect it to PC, start ALP and select the menu item **Device > Firmware update**.

Click **Select** to select the device in the opened dialog. The update process starts. The message about the update result will be shown upon completion of the update.

5 Device information

To obtain information about the software, the target device and the connected device use the menu item **Device > Information...** or the icon  on the toolbar. The window **Information** will open:




Fig. 5.1

The window contains the following information:

Target device – the device selected when the project was created

Software version at project creation – the version of the software in which the project has been created, this version may differ from the current software version

Software version at project modification – the version of the software in which the project has been modified, this version may differ from the current software version

Connected device information – the information about the device connected to the PC

Export into project – the button is active only if the device PR114-224.8D4A.4RXXXX is connected. It can be used to export the real output types of the connected device into the project. Alternatively the type of each output can be manually changed in **Property Box** in accordance with the hardware.

6 Device configuration

The configuration of the device is a part of a project and can be set using the menu item **Device > Configuration**. The dialog window **Device configuration** consists of two parts. The configurable parameters of the device are presented in the parameter tree in the left part of the window. The content of a group is presented in the right part.

The content of the parameter tree depends on the target device and can include the following groups:

- Display
- Clock
- Interfaces
- Inputs
- Outputs

All the settings are saved in the project, except the clock settings. The configuration is also possible without connecting the device.

6.1 Display

If the target device has a display, the following parameters can be set:

Backlight – the duration of the backlight since the last user activity

Brightness – display brightness 0...100%

Contrast – display contrast 0...100%

The button **Read** can be used to read out the current display settings from the connected device.




Fig. 6.1

6.2 Clock

The date and the time can be set in the group **Clock** if the target device has an integrated real-time clock.

Device configuration




Fig. 6.2

To synchronize the device clock with the PC clock, check the checkbox **Synchronizing with PC**. In this case the fields **Date** and **Time** will be inactive. To set the device clock to the new values click the button **Save** in the section **Date/Time**.




Fig. 6.3

Specify the clock error in seconds per month in the field **Deviation** to set the clock correction. Enter a negative value if the device clock is too fast.




Fig. 6.4

To set the device clock correction, click the button **Save** in the section **Correction**.

The button **Read** can be used to read the current time settings from the connected device.

6.3 Interfaces

If the target device has a serial network interface RS485, its parameters can be set in the group **Interfaces**.

By default, there is one interface configured as a Slave and assigned to the hardware slot 1 with default settings: Master device with the name PR and the network address 16.

If the number of interfaces on the target device can be changed, interfaces can be added or deleted in the configuration, but their number cannot exceed the number of the existing slots (see 6.3.1).

If an interface is configured as a Master, Slaves can be added or deleted in the configuration, but their number cannot exceed 16.

6.3.1 Add / remove interface

If the device has a slot, for which no interface is configured, an appropriate interface can be added using the item **Add Interface** in the context menu.




Fig. 6.5

An interface of the selected type with default settings will be added.

Depending on the PR model, the interface can be replaced by another type of interface or removed using the context menu.




Fig. 6.6

6.3.2 RS485 Interface configuration






Fig. 6.7 Interface configuration

Device configuration

The type of the interface (RS485), the number of the assigned slot and the mode (Master/Slave) are displayed in the tree.

To establish the connection over the interface, it has to be configured. The parameters of the interface are displayed on the right part of the window. The default value depends on the target device. The parameters **Protocol** and **Interval between requests** are only in the Master mode available. In the Slave mode they are inactive and grayed out.

The icon  **As standard** is used to save the settings as default values for future projects.

The icon  **Factory settings** is used to apply the unchangeable factory settings.

The button **Read** is used to read out the current settings from the connected device.

Use the button **Close** to save the settings in the project and close the dialog.

6.3.2.1 Master mode

In the Master mode all the Slaves connected to the interface are requested. Select the mode **Master** in the parameter list, set other connection parameters and add the required number of Slaves using the item **Add slave** in the interface context menu.






Fig. 6.8 Master configuration in master mode

The added Slave device will be displayed in the tree below the name of the interface with the name and the address. Select the Slave and configure it in the right part of the window.

In the upper part of the window the parameters of the Slave can be set (see Fig. 6.9).

To save the Slave device with its configuration as a template use the context menu (see Fig. 6.8) or click the icon  **Save Slave as a template** (see Fig. 6.9). The template file will be saved with the extension *.dvtp and can be used in other projects.

To delete the Slave device use the context menu (see Fig. 6.8) or click the icon  **Delete Slave** (see Fig. 6.9).




Fig. 6.9 Slave configuration in master mode

- **Name** – the name of the Slave displayed in the tree
- **Address** – the network address of the Slave
- **Query cycle (ms)** – the time interval between queries. A query comprises the number of requests according to the number of variables listed for the Slave. The valid range is 0...65535 ms.
- **Timeout (ms)** – the time that request can take before the attempt is considered as failed. The valid range is 0...65535 ms.
- **Retries, max.** – the number of the failed request attempts, before query is stopped and the status of the device changes. The valid range is 0...255.
- **Burst request** – group request of consecutive registers to increase the data throughput
- **Status variable** – the Boolean variable used to record the device status:
 - 1 – the device functions properly
 - 0 – connection with the device is lost. Use the button "..." to select a variable.
- **Start query** – the Boolean variable to control the query:
 - 0 – query disabled
 - 1 – query enabled. Use the button "..." to select a variable.
- **Change register order** – determines the register order in two-register variables
- **Change byte order** – determines the byte order in the register
- **Comment** – the text comment to describe the device




Fig. 6.10 Query time diagram

The list of the variables to be requested from this Slave is in the lower part of the window. Each variable created in this list can be found in the summary table of variables under the tab **Network X** with a separate list of variables for each slave device (see 7.5).

Add a variable by clicking the icon **Add variable** and set the parameters of the variable.





Fig. 6.11 Variable configuration in master mode

- **Name** – the name of the variable
- **Type** – the data type of the variable: Boolean, Integer or Real
- **Register** – the register address
- **Bit** – the number of the bit of the register (0...15) (only for Boolean variables)
- **Read function / Write function** – selection of the read / write function or disable reading / writing.
- **Number of registers** – the number of registers occupied by the variable (only for integer variables)
- **Start reading** – the Boolean variable assigned for forced reading of the requested variable
- **Start writing** – the Boolean variable assigned for forced writing of the requested variable
- **Status variable** – the integer variable used to record the error code in case of error
- **Comment** – the text comment to describe the requested variable

To create several variables with similar settings, select a variable and click the icon  **Replication**.





Fig. 6.12 Variable replication

- **Name** – the name of the replicated variable
- **Start number** – the initial number (will be added to the name of the replicated variable)
- **Quantity** – the quantity of the replicated variables
- **Address step** – the address increment

Device configuration

Click **OK** to add the replicated variables to the list of variables. To remove the variable from the list use the icon  **Delete variable**.

6.3.2.2 Slave mode

If an RS485 interface is added to the tree, the default mode is Slave and the default Master with the name PR and the address 16 is added below. Select the interface to set other connection parameters.




Fig. 6.13 Slave configuration in slave mode

Select the Master to set the parameters for data exchange.




Fig. 6.14 Master configuration in slave mode

The common parameters for data exchange can be set in the upper window part.

- **Name** – the name of the Master displayed in the tree
- **Address** – the network address of the Master
- **Change register order** – determines the register order in two-register variables
- **Change byte order** – determines the byte order in the register
- **Comment** – the text comment to describe the device

The list of the variables to be requested by the Master is in the lower part of the window. Each variable created in this list can be found in the summary table of variables under the tab **Network X** (see 7.5).

Add a variable by clicking the icon  **Add variable** and set the properties of the variable.

Device configuration





Fig. 6.15 Variable configuration in slave mode

- **Name** – the name of the variable
- **Type** – the data type of the variable: Boolean, Integer or Real
- **Register** – the register address. The range of the available addresses is specified in the user manual of the device.
- **Comment** – the text comment to describe the requested variable

To create several variables with similar settings, select a variable and click the icon  **Replication**.





Fig. 6.16 Variable replication

- **Name** – the name of the replicated variable
- **Start number** – the initial number (will be added to the name of the replicated variable)
- **Quantity** – the quantity of the replicated variables
- **Address step** – the address increment

Click **OK** to add the replicated variables to the list of variables. To remove the variable from the list use the icon  **Delete variable**.

6.4 Inputs

The content of the branch **Inputs** depends on the resources of the target device. It can be analog and digital inputs (Fig. 6.18, 6.19).

For further details about the configuration of the inputs, refer to the user manual of the device.

The parameter **Comment** is the common setting for all types of inputs. The text in this field will be displayed in the tooltip, when the mouse is over the input in the workspace.

Device configuration




Fig. 6.17 PR200 digital input configuration





Fig. 6.18 PR200 analog input configuration

7 Variables

To see all variables created in the project click the icon  on the toolbar or use the item **Device > Variables** in the main menu.

There are following arts of variables:

- Standard
- Service
- Network

The variables are organized on separate tabs in the table.

Only standard and network variables can be created or deleted.




Fig. 7.1

7.1 Properties

Name	The name of the variable
Data type	Boolean, Integer or Real (see 7.2 “Data type”)
Persistence	The variable is stored in the non-volatile memory of the device and become retain variable . For detailed information about storage time and memory size, refer to the user manual of the device.
Default value	The value at the fist start of the program, until the new value is assigned to. Available only for retain variables.
Used in project	The variable has a reference to an element in the program
Comment	The text displayed in the tooltip in the workspace, when the mouse is over the variable

7.2 Data type

The variables of the following types can be used in a program:

- Boolean (**BOOL**)
- Integer (**INT**)
- Real (**REAL**)

Note: Different devices can have restrictions related to support of certain types of variables.

1. Boolean (BOOL)

A variable of this type has only two possible values: 1 (True) or 0 (False).

The connection lines between the Boolean variables in the circuit program are displayed in gray.




Fig. 7.2 Boolean connections

2. Integer (INT)

A variable of this type has a range 0...4294967295 (4 Byte).

The connection lines between the Integer variables in the circuit program are displayed in red.




Fig. 7.3 Integer connections

3. Real (REAL)

A variable of this type has a value in the range from $\approx 1,175e^{-38}$ to $\approx 3,4e^{+38}$. It is represented by a floating-point number of single-precision (4 Byte).

The connection lines between the Real variables in the circuit program are displayed in violet.




Fig. 7.4 Real connections

7.3 Standard variables

These are common variables used for connection between elements of the circuit program, inputs, outputs and display forms.

Standard variables are listed in the variable table under the tab **Standard**.

To create a variable select the empty row in the table, enter the variable name and specify its data type. Other parameters are unessential. The created variable can be used in the project.

Use the item **Show references** in the variable context menu to see where the variable is used in the project.




Fig. 7.5

Variables

In the dialog window **References to the variable** select the reference you want to delete and click **Delete**.

To remove the variable from the table use the item **Delete variable** in its context menu.

7.4 Service variables

Service variables are associated to the device settings and can differ depending on the device. Service variables are related to the hardware features, such as real-time clock, interface card in the slot etc. and cannot be deleted. They can have read/write restrictions.

The service variables are listed in the variable table under the tab **Service**.

The blocks of service variables are shown in the circuit program with a gray background.




Fig. 7.6 Service variables in the table




Fig. 7.7 Service variables in a diagram

7.5 Network variables

Each interface slot has a separate tab in the table.

If the interface is configured as a Master, there are separate tabs for each Slave device within the slot tab (see Fig. 7.8). The Slave tab contains the variables to be requested for this Slave device.




Fig. 7.8 Network variables for Master interface

For more details about network variables for Master interface see 6.3.2.1.

If the interface is configured as a Slave, all network variables to be requested by the Master are shown in one list (see Fig. 7.9). For more details about network variables for Slave interface see 6.3.2.2.

Variables

Select a network variable or create a new one

Name	Data type	Register address	Bit number	Comment
Var1	INT	516		
Var11	INT	515		
Var12	INT	514		
Var13	INT	513		
Var14	INT	512		
< none >	INT	517		

OK

Fig. 7.9 Network variables for Slave interface

8 Circuit program development

It is recommended to start the creation of a circuit program with planning. The plan must describe all possible states of the device during operation in form of diagram of modes, table of I/O states, electrical or functional diagram, etc.

After all the operation tasks are described, the program can be developed using standard elements from the toolbar **Insert** (see Table 3.6) and specific elements from the project library (see 10 “Library”). The project library contains the functions and the function blocks available for the target device and the macros added to the project. For further information about macros, please refer to section 11 “Macros”.

To connect elements use the left mouse.




Fig. 8.1

The parameters of the program elements can be set in the panel **Property Box** (see 3.6).




Fig. 8.2

8.1 Using of library elements

To place a library element in the circuit program, select the desired element in **Library Box** and move it onto the workspace by drag-and-drop.




Fig. 8.3

8.2 Using of variables

To add a variable to the program click the corresponding icon on the toolbar **Insert** (see Table 3.6), then click the place in the workspace to place the variable block.



Fig. 8.4




Fig. 8.5

To reference a variable to the block use the button "..." in the row **Variable** in Property Box.




Fig. 8.6

Select a variable or create a new one in the open variable list and confirm with **OK**.




Fig. 8.7

Use network variables to exchange data with other devices connected to the PR over network. For further details about using of network variables, refer to section 8.9 "Network data exchange".

If a variable block is highlighted in red during programming, it means that the creation is incorrect or not completed.




Fig. 8.8

The information about the error is displayed in the status bar.

8.3 Using of constants

To add a fixed value to the program click the icon on the toolbar **Insert** (see Table 3.6), then click the place in the workspace to place the constant block.

Circuit program development




Fig. 8.9


Select the data type using the button "... " in the row **Data type** and enter the value in the row **Constant value** in Property Box.

8.4 Reading / writing for function blocks

The block **WriteToFB** is used to change a parameter of a function block during the process.

Example:

The value of the parameter **ON-duration** of the function block **BLINK1** should be 2 or 10 depending on the value at the input I5.

To add a block **WriteToFB** to the program click the icon  on the toolbar **Insert** (see Table 3.6), then click the place in the workspace to place the block.

Go to Property Box, select the function block **BLINK1** in the row **Function block** and the parameter of the FB in the row **Parameter in FB** (see Fig. 8.10).




Fig. 8.10

The block **ReadFromFB** is used to read the current value of a function block parameter and use it in the program.





Fig. 8.11

8.5 Using of feedbacks

A feedback is used to set the value from the block output to the block input, delayed for one cycle.

Click the icon  on the toolbar **Insert** (see Table 3.6) and draw a line between the output and the input of a function or a function block. The feedback is displayed as a red dashed line with an arrow.




Fig. 8.12

Example:

A constant value 1 is transmitted to the input I1 of the addition block ADD (Integer). A value from the block output (Q) calculated in the previous cycle is transmitted to the input I2 over the feedback.




Fig. 8.13

Table 8.1 Cycle signal values

Cycle	1	2	3	4	5	6	7	8	9	10
I2	0	0	1	1	2	2	3	3	4	4
Q	1	1	2	2	3	3	4	4	5	5

8.6 Using of comments

Comments can be used to explain the program.




Fig. 8.14

To add a comment to the program, click the icon **A** on the toolbar **Insert** (see Table 3.6), then click the place in the workspace to place the comment block and draw a rectangle with the left mouse button.




Fig. 8.15

Double-click the text box to write the text.




Fig. 8.16

The parameters of the comment can be changed in Property Box.




Fig. 8.17

8.7 Arrange elements

Sequence numbers of the function blocks can be automatically re-assigned by clicking the button **Arrange elements** on the toolbar **Service** (see Table 3.6). The blocks of the same type will be numbered sequentially from top to bottom and from left to right.




Fig. 8.18

8.8 Execution sequence

Calculation of the values for outputs and feedbacks in a circuit program is performed in a certain order. To see this order click the arrow near the icon on the toolbar **Service** and select the **Feedbacks** or **Outputs** (see Table 3.6).




Fig. 8.19

To change the order double-click the output or feedback and enter the desired number.







Fig. 8.20

Click the icon  to deactivate the edit mode.



8.9 Network data exchange

The network input and output variables are special type of variables for data exchange between devices connected to a common network.

The variables, which can be read via the network, are called Network output variables (.

The variables, which can be written via the network, are called Network input variables (.

To add a network variable to the program proceed as follows:

- Click the icon  or  on the toolbar **Insert** (see Table 3.6).
- Click the place in the workspace to insert the variable.
- Click the button "..." in the row **Variable** in Property Box to select a variable for the block.




Fig. 8.21

- Select a variable or create a new one in the opened variable list and confirm with OK. The selected variable is referenced to the variable block.




Fig. 8.22

- Connect the network variable to the desired element in the workspace.




Fig. 8.23

It is recommended to start programming with the creation of variables in the variable table.

8.10 Simulation mode

Use the simulation mode to proof the correctness of the created program. Only offline simulation is provided. The simulation mode enables to analyze the values of all signals within the circuit program. Change the values at the digital and analog inputs as well as of variables and constants and check the values at the outputs.

To start the simulation mode, press the button **Simulation** on the toolbar **Service** (see Table 3.6). A new toolbar **Simulation** is displayed with the following controls:




Fig. 8.24

1. Start permanent simulation mode
 2. Step-by-step simulation. If the icon is clicked, one program cycle will be executed.
 3. Break simulation. Click the icon once more to continue the simulation.
 4. Stop simulation
 5. Simulation refresh time (Cycle start period)
 6. Cycle time
 7. Selection of measurement units for cycle time: milliseconds, seconds, minutes, hours
- If there are function blocks of type CLOCK or CLOCKW in the project (available only for devices with a real-time clock), an additional toolbar **Calendar** is displayed during simulation.




Fig. 8.25

The parameter **Refresh time (ms)** specifies the cycle start period.

Circuit program development

The parameter **Cycle time** specifies the cycle duration.

If you want to change to the program, stop the simulation mode.

To set the value for the input signal click the input block.




Fig. 8.26

The value of a network variable can be set as well. Click the network variable in the simulation mode, enter the prepared value in the opened dialog and confirm with **OK**.




Fig. 8.27

Notes:

- Macros are excluded from simulation. Simulation for macros should be performed separately in the workspace of the macro.
- Simulation cannot be performed for blocks without connection with a device output or a network variable.

9 Display programming

To determine the information to be displayed, use the tab **Display Manager** in the upper left corner of the window. Display Manager is available only for target devices with display. The display is programmed using one or more display forms with jump conditions so that the operator can switch between them to see the desired information.

Display Manager is divided in two parts: the graphical structure of display forms in the upper part and the form properties in the lower part.




Fig. 9.1




Fig. 9.2

By default, the graphical structure consists of one form.




Fig. 9.3

9.1 Display form structure

Use the buttons **Add display form** and **Delete display form** in the Display Manager toolbar to add or remove a display form.

Use the buttons **Up** and **Down** to change the order of the forms in the structure.




Fig. 9.4

9.2 Display properties

Select the form in the structure to show its properties and specify the form name.
 If there are two or more display forms in the project, jump conditions for switching between them can be defined.




Fig. 9.5

Click the button "..." in the row **to display form** to open the dialog **Jump**.
 Select the form in the section **Display form selection**.
 Select the event in the section **Jump condition**, as a device event or change of a variable by value.




Fig. 9.6

A button event can be selected as a **Device event**.
 A Boolean variable can be selected for **Change by value**.




Fig. 9.7




Fig. 9.8

Confirm with **OK**. The created jump will be shown in the structure.




Fig. 9.9

9.3 Display editor

Double-click the form or click the button **Edit** to open the form in a separate workspace for editing.

Display programming





Fig. 9.10

A form may consist of several rows; the operator can switch between them using the function buttons on the device. A display form is shown in the workspace with icons  on the right side, which are used to change the number of the displayed rows. The rows displayed first are outlined.

Put the display elements from the Library Box onto the form by drag-and-drop. For element descriptions refer to Display elements.

10 Library

If a project is open, the panel **Library Box** contains the following libraries:

- **Functions**
- **Function blocks**
- **Project macros**

Select an icon in the lower part of the panel to show the respective content.

The library **Project macros** comprises the macros created by the user, imported or included to the project from Online Macro Database.

View options can be changed using the icons located on the toolbar of the panel.

10.1 Functions

The library contains the following function groups:

- Logical operators
- Mathematical operators
- Relational operators
- Bitshift operators
- Bit operators

10.1.1 Logical operators

- Conjunction (AND)
- Disjunction (OR)
- Negation (NOT)
- Exclusive OR (XOR)

The logical operators can operate with Boolean or Integer variables.

If the input values are Integer, the operation will be performed for each bit separately and the output is Integer too.

10.1.1.1 Conjunction (AND)




Fig. 10.1

The output **Q** is True if both inputs are True. The function **AND** represents a serial connection in an electrical circuit.

Table 10.1 Truth table

I1	I2	Q
0	0	0
0	1	0
1	0	0
1	1	1

Library

10.1.1.2 Disjunction (OR)




Fig. 10.2

The output **Q** is True if at least one of the inputs is True. The function **OR** represents a parallel connection in an electrical circuit.

Table 10.2 Truth table

I1	I2	Q
0	0	0
0	1	1
1	0	1
1	1	1

10.1.1.3 Negation (NOT)




Fig. 10.3

The function **NOT** inverts the signal. The output **Q** is True if the input is False and vice versa.

Table 10.3 Truth table

I1	Q
0	1
1	0

10.1.1.4 Exclusive OR (XOR)




Fig. 10.4

The output **Q** is True if only one of the inputs is True.

Table 10.4 Truth table

I1	I2	Q
0	0	0
0	1	1
1	0	1
1	1	0

Library

10.1.2 Mathematical operators

There are different operators for different data types:

Table 10.5

Operator	Integer	Real
Addition	ADD	fADD
Subtraction	SUB	fSUB
Multiplication	MUL	fMUL
Division	DIV	fDIV
Modulo operation	MOD	-
Power function	-	fPOW
Absolute value	-	fABS

10.1.2.1 Addition (ADD, fADD)



Fig. 10.5

The function **ADD** operates with Integer variables, the function **fADD** operates with Real variables.

The output value **Q** is the sum of the input values.

Example:




Fig. 10.6

The output value may not exceed 4294967295 (32 bits). If it does happen, the extra bits will be truncated.

10.1.2.2 Subtraction (SUB, fSUB)




Fig. 10.7

The function **SUB** operates with Integer variables, the function **fSUB** operates with Real variables.

The output value **Q** is the result of subtraction of the value **I2** from the value **I1**.

Example 1:




Fig. 10.8

If the value **I1** is less than the value **I2**, the output will be calculated as follows:

$$Q = I1 + 0x100000000 - I2$$

$$0x100000000 = 4294967296$$

Example 2:




Fig. 10.9

10.1.2.3 Multiplication (MUL, fMUL)

$$I1 * I2 = Q$$



Fig. 10.10

The function **MUL** operates with Integer variables, the function **fMUL** operates with Real variables.

The output value **Q** is the product of the input values.

Example:




Fig. 10.11

The output value may not exceed 4294967295 (32 bits). If it does happen, the extra bits will be truncated.

10.1.2.4 Division (DIV, fDIV)

$$I1 / I2 = Q$$




Fig. 10.12

The function **DIV** operates with Integer variables, the function **fDIV** operates with Real variables.

The output value **Q** is the quotient of the input values, where the value **I1** is the dividend and the value **I2** is the divisor.

If the quotient is not an integer, it will be rounded down to an integer.

In case of division by 0 the output value is 0xFFFFFFFF.

10.1.2.5 Modulo operation (MOD)




Fig. 10.13

The function **MOD** operates with Integer variables. The output **Q** is a remainder of the division of input values.

$$Q = \left[\frac{V1}{V2} \right]$$

Example:




Fig. 10.14

10.1.2.6 REAL-Power function (fPOW)

$$I1^{(I2)} = Q$$



Fig. 10.15

The function **fPOW** operates with Real variables.

The output value **Q** is the value **I1** raised to the power of the value **I2**.

Example:




Fig. 10.16

10.1.2.7 REAL-Absolute function (fABS)

$$|I1| = Q$$




Fig. 10.17

The function **fABS** operates with Real variables.

The output value **Q** is an absolute value of the input value.

$$Q = |V|$$

Examples:




Fig. 10.18

10.1.3 Relational operators

The relational operators are functions that test or define some kind of relation between two or more values.

10.1.3.1 Equal (EQ)




Fig. 10.19

Library

The function **EQ** operates with Integer variables.

The output value **Q** is True if the value **I1** and the value **I2** are equal.

Table 10.6 Truth table

I1 / I2	Q
I1 = I2	1
I1 > I2	0
I1 < I2	0

Examples:




Fig. 10.20

10.1.3.2 Greater than (GT, fGT)




Fig. 10.21

The function **GT** operates with Integer variables, the function **fGT** operates with Real variables.

The output value **Q** is True if the value **I1** is greater than the value **I2**.

Table 10.7 Truth table

I1 / I2	Q
I1 = I2	0
I1 > I2	1
I1 < I2	0

Examples:




Fig. 10.22

Library

10.1.3.3 Binary selection (SEL)




Fig. 10.23

The function **SEL** operates with Integer variables, the function **fSEL** operates with Real variables.

If **I1** = False, the output value **Q** is set to the value **I2**, else to the value **I3**.

Table 10.7 Table of states

I1	Q
0	I2
1	I3

Examples:




Fig. 10.24

10.1.4 Bitshift operators

The bitshift operators treat a variable as a series of bits that can be moved (shifted) to the left or right.

10.1.4.1 Shift register left (SHL)




Fig. 10.25

The function **SHL** operates with Integer variables. It is used to shift all bits of the operand **X** to the left by the **N** number of bits; vacated bits are zero-filled. The result is set to the output **Q**.




Fig. 10.26

Example: left shift of the number 38 (decimal) = 00100110 (binary) by 2 bits




Fig. 10.27

10.1.4.2 Shift register right (SHR)




Fig. 10.28

The function **SHR** operates with Integer variables. It is used to shift all bits of the operand **X** to the right by the **N** number of bits; vacated bits are zero-filled. The result is set to the output **Q**.

Example: right shift of the number 152 (decimal) = 10011000 (binary) by 2 bits




Fig. 10.29

10.1.5 Bit operators

The bit operator treats a value as a series of bits to perform operations on one or more individual bits of an operand.

10.1.5.1 Read single bit (EXTRACT)




Fig. 10.30

The output value **Q** (Boolean) of the function **EXTRACT** is the value of bit **N** (Integer) in the operand **X** (Integer). The bit numbering is zero-based.

Example: reading of the 5th bit from the number 81 (decimal) = 1010001 (binary):




Fig. 10.31

10.1.5.2 Set single bit (PUTBIT)




Fig. 10.32

This output value **Q** (Integer) is the value of the operand **X** (Integer) where the bit **N** (Integer) is set to the value at the input **B** (Boolean). The bit numbering is zero-based.

Example: setting of the 4th bit to 1 in the number 38 (decimal) = 100110 (binary):




Fig. 10.33

10.1.5.3 Decoder (DC32)



Fig. 10.34

The decoder converts a binary code at the input to a position code at the output. Decoding is preceded by the bitwise logical operation **AND** with the operand 0x1F (11111b).

Table 10.8 Truth table

Binary code							Position code							
5	4	3	2	1	32	31		6	5	4	3	2	1	
0	0	0	0	0	0	0	...	0	0	0	0	0	1	
0	0	0	0	1	0	0		0	0	0	0	1	0	
0	0	0	1	0	0	0		0	0	0	1	0	0	0
0	0	0	1	1	0	0		0	0	1	0	0	0	0
0	0	1	0	0	0	0		0	1	0	0	0	0	0
...										
1	1	1	0	1	0	0		0	0	0	0	0	0	
1	1	1	1	0	0	1		0	0	0	0	0	0	
1	1	1	1	1	1	0		0	0	0	0	0	0	

Example:




Fig. 10.35

10.1.5.4 Encoder (CD32)




Fig. 10.36

The encoder converts a position code at the input to a binary code at the output.

If there is more than one "1" bits in the position code, the encoder operates only with the most significant "1" bit.

For truth table see table 10.8 for Decoder.

10.2 Function blocks

The library contains the following FB groups:

- Triggers
- Timers
- Generators
- Counters
- Control

10.2.1 Triggers

- RS trigger reset dominant (RS)
- SR trigger set dominant (SR)
- Rising edge (RTRIG)
- Falling edge (FTRIG)
- D-trigger (DTRIG)

10.2.1.1 RS trigger reset dominant (RS)




Fig. 10.37

The output **Q** is True with a rising edge at the input **S** (Set) and False with a rising edge at the input **R** (Reset). The input **R** has higher priority.




Fig. 10.38

10.2.1.2 SR trigger set dominant (SR)




Fig. 10.39

The output **Q** is True with a rising edge at the input **S** (Set) and False with a rising edge at the input **R** (Reset). The input **S** has higher priority.




Fig. 10.40

10.2.1.3 Rising edge (RTRIG)




Fig. 10.41

Detector for a rising edge

The output **Q** remains False until a rising edge at the input **I**. As soon as the input **I** becomes True, the output will be True and remains for one program cycle.




Fig. 10.42

10.2.1.4 Falling edge (FTRIG)




Fig. 10.43

Detector for a falling edge

The output **Q** remains False until a falling edge at the input **I**. As soon as the input **I** becomes False, the output will be True and remains for one program cycle.




Fig. 10.44

10.2.1.5 D-trigger (DTRIG)




Fig. 10.45

D-trigger generates a pulse at the output **Q** with the pulse duration specified at the input **D** and synchronized with the clock pulse at the input **C**.

If the input **D** is True, the output **Q** will be True with a rising edge of the clock pulse at the input **C**.

If the input **D** is False, the output **Q** will be False with a rising edge of the clock pulse at the input **C**.




Fig. 10.46

The output **Q** can be forced set to True with a rising edge at the input **S** (Set) and forced reset to False with a rising edge at the input **R** (Reset), regardless of the states of the inputs **C** and **D**. The input **R** has higher priority.

10.2.2 Timers

- Pulse (TP)
- ON-delay timer (TON)
- OFF-delay timer (TOF)
- Timer (CLOCK)
- Weekly timer (CLOCKW)

10.2.2.1 Pulse (TP)




Fig. 10.47

The block **TP** is used to generate one output pulse with the specified pulse duration.




Fig. 10.48

Library

The output **Q** is set True with a rising edge at the input **I** for the time specified at the input **T**. During this time, the output **Q** remains True regardless of the signal change at the input **I**. On the termination of the pulse, the output **Q** is reset to False.

The pulse duration and the time unit can be set in Property Box.




Fig. 10.49

Time range: 0...4147200000 ms or 48 days.

10.2.2.2 ON-delay timer (TON)




Fig. 10.50




Fig. 10.51

The output **Q** = False if the input **I** = False. With a rising edge at the input **I**, the delay time specified at the input **T_{ON}** will start to be counted. When the time **T_{ON}** is elapsed, the output **Q** becomes True and remains until a falling edge at the input **I**. Input changes shorter than **T_{ON}** will be ignored.

The delay time and the time unit can be set in Property Box.




Fig. 10.52

Time range: 0...4147200000 ms or 48 days.

10.2.2.3 OFF-delay timer (TOF)




Fig. 10.53

Library

The output $Q = \text{False}$ if the input $I = \text{True}$. With a falling edge at the input I , the delay time specified at the input T_{OFF} will start to be counted. When the time T_{OFF} is elapsed, the output Q becomes False and remains until a rising edge at the input I . Input changes shorter than T_{OFF} will be ignored.

The delay time and the time unit can be set in Property Box.




Fig. 10.54

Time range: 0...4147200000 ms or 48 days.

10.2.2.4 Timer (CLOCK)




Fig. 10.55

The block **CLOCK** is an interval timer controlled by a real-time clock.




Fig. 10.56

The times T_H and T_L can be set in Property Box.




Fig. 10.57

Time range: from 0.00 seconds to 24 hours.

If $T_H < T_L$, the state of the output Q is as follows:




Fig. 10.58

10.2.2.5 Week timer (CLOCKW)




Fig. 10.59

The block **CLOCKW** is an interval timer with the parameter **Weekday** controlled by a real-time clock.




Fig. 10.60

The times T_H and T_L can be set in Property Box.




Fig. 10.61

Time range: from 0.00 seconds to 24 hours.

10.2.3 Generators

- Pulse generator (BLINK)

10.2.3.1 Pulse generator (BLINK)




Fig. 10.62

If the input **I** is set to True, the block **BLINK** generates a square wave on the output **Q** with a period of $T_H + T_L$ starting with an interval of the duration of T_L , followed by a pulse of the duration of T_H . It continues that way until the input **I** is False.




Fig. 10.63

The times T_H and T_L and the time units can be set in Property Box.




Fig. 10.64

Time range: 0...4233600000 milliseconds or 49 days.

10.2.4 Counters

- Threshold counter with self-reset (CT)
- Universal counter (CTN)
- Threshold counter (CTU)

10.2.4.1 Threshold counter with self-reset (CT)




Fig. 10.65

The output **Q** is of type Boolean. If the number of pulses counted on the input **C** exceeds the threshold (**Setting**) specified at the input **N**, the output **Q** will be set to True and remains for one program cycle.




Fig. 10.66

The parameters **Setting** and **Persistence** can be set in Property Box.




Fig. 10.67

Threshold range: 0...65535.

If **Persistence** = Yes, the state of the counter will be saved in the non-volatile memory.

10.2.4.2 Universal counter (CTN)




Fig. 10.68

The output **Q** is of type Integer. A rising edge at the input **U** increases the value at the output **Q** by 1. A rising edge at the input **D** decreases the value at the output **Q** by 1.

If the input **R** = True, the output **Q** is set to the value **Setting** at the input **N**.




Fig. 10.69

The input **U** has higher priority than the input **D**.

The parameters **Setting** and **Persistence** can be set in Property Box.




Fig. 10.70

Setting range: 0...65535.

If **Persistence** = Yes, the state of the counter will be saved in the non-volatile memory.

10.2.4.3 Threshold counter (CTU)




Fig. 10.71

The output **Q** is of type Boolean. If the number of pulses counted on the input **C** exceeds the threshold (**Setting**) specified at the input **N**, the output **Q** will be set to True and remains until a rising edge at the input **R**. The input **R** has higher priority than the input **C**.




Fig. 10.72

The parameter **Setting** can be set in Property Box.




Fig. 10.73

Threshold range: 0...65535.

10.2.5 Controllers

- PID controller (PID)

10.2.5.1 PID controller (PID)




Fig. 10.74




Fig. 10.75

The function block **PID** is used for implementation of the proportional-integral-derivative control.

Table 10.9 PID block inputs/outputs

Name	Type	Description	Values
E	BOOL	Enable control (0 = Off, 1 = On). If disabled, the output Pwr is set to the value of the parameter Output safe state .	0/1
Pv	REAL	Process value	
Sp	REAL	Setpoint	
Pwr	REAL	Output power, %	0-100

Table 10.10 PID block parameters

Name	Type	Description	Values
Control mode	BOOL	0-Heating 1-Cooling	0/1
Output safe state	REAL	Output value in off-state, %	0-100
Proportional gain (Kp)	REAL	Coefficient for proportional control	0-100
Integration time (Ti), s	REAL	Time constant for integral control, sec.	0-9999
Derivative time (Td), s	REAL	Time constant for derivative control, sec.	0-100
Max. output value	REAL	Output upper limit, % (default 80%)	0-100
Min. output value	REAL	Output lower limit, % (default 20%)	0-100
Start Auto-Tuning	BOOL	Start auto-tuning if True. The variable can be set only using the block WriteToFB .	0/1

Loop tuning

Tuning of a control loop is the adjustment of its control parameters (proportional gain, integral time, derivative time) to the optimum values for the desired control response.

Manual tuning can be performed using the blocks **WriteToFB** and **ReadFromFB**:

The parameters can be set using the block **WriteToFB** (See Fig. 10.76) or in Property Box (See Fig. 10.77). The following parameters can be read using the block **ReadFromFB**:

- Calculated proportional coefficient
- Calculated integration time
- Calculated derivative time
- Flag "Stop Auto-Tuning"

For further instructions see section 8.4 "Reading / writing for function blocks".




Fig. 10.76




Fig. 10.77

Library

To use auto-tuning, add the block **WriteToFB** to the circuit program and set the reference to the variable **Start Auto-Tuning** of the FB **PID**. To start the auto-tuning enable control ($E = \text{True}$) and set the variable **Start Auto-Tuning** to **True**.




Fig. 10.78

Upon completion of the auto-tuning, the new values of the parameters **Kp**, **Ti** and **Td** are calculated and the variable **Stop Auto-Tuning Flag** becomes **True**. If **Start Auto-Tuning** becomes **False**, **Stop Auto-Tuning Flag** will be set to **False** as well.

If you reset the variable **Start Auto-Tuning** to **False** before the completion of auto-tuning, the process will be stopped, the flag set to **False** and new coefficient values not calculated.

During the process of the auto-tuning, a test signal limited by parameters **Max. output value** and **Min. output value** is applied to the block output.

Auto-tuning for Heating Mode

1. The current value is less than the setpoint, the output is set to the maximum value.
2. As soon as the current value exceeds the setpoint, the output is set to the minimum value.
3. Reiteration of the steps 1 and 2.
4. Calculated PID coefficients are saved into appropriate FB variables and the stop flag is set to **True**.

If the maximum output value is not enough to reach the setpoint, the auto-tuning cannot be completed and will continue until it is stopped manually.

10.3 Project macros

Macro is a function blocks created in the same way as a main program. It can be saved in the Library for further use in the same project or exported to a file for use in other projects. Macros can be also imported from a file or downloaded from the Online Macro Database into the project library.

10.3.1 New macro

There are some specific aspects of working with macros:

1. Select **File > New macro** in the menu. In the opened dialog specify the number of inputs and outputs and confirm with **OK**. The new empty macro will be opened in a separate workspace.




Fig. 10.79

The number of inputs and outputs can be always changed using context menu in the workspace.




Fig. 10.80

To remove an input or an output, click it with the right mouse button and select **Delete**.

Data type for each input and output can be selected in Property Box.




Fig. 10.81

2. Give a name, a description and a group to the macro in Property Box.




Fig. 10.82

The name is displayed in the workspace tab. It is the name of the macro in the project. The description will be displayed in the tooltip, when the mouse is over the macro in the workspace. The group name is used in the library.

Library

- To use the macro in the project drag-and-drop it from the Library Box into the workspace of the main program.




Fig. 10.83

- The macro can be saved in the project as a new macro with another name using the menu item **File > Save macro as...**




Fig. 10.84

To save a macro as a file see 10.3.2 “Export macro”. To import a macro from a file see 10.3.3 “Import macro”.

- If a function block is used in the macro, the user can define whether the FB properties are available as properties of the macro in the main program. If the parameter **Use in macro** is set to **Yes**, the parameters of the FB became parameters of the macro and a new option **Parameter of macro** is added to the macro. With this option the user can define the name of each FB parameter in the macro.




Fig. 10.85

10.3.2 Export of macro

A macro can be exported to the file if the macro workspace is active. To open the project macro in the separate workspace, select it in the library and use the item **Edit macro** in the macro context menu.




Fig. 10.86

To export the macro use the menu item **File > Export Macro**, select the path, specify the filename and confirm with **OK**. The macro will be saved with the file extension ***.tpl**. Finally the report about failure/successful export of the macro will be displayed.

10.3.3 Import of macro

A macro can be imported from the file into the library if the main program is active. Use the menu item **File > Import macro**. In the opened dialog select the file and confirm with **OK**. The macro will be added to the library into the section **Macros**.

10.3.4 Online Macro Database

To download macros from **Online Macro Database** an internet connection is needed. Select the menu item **File > Online Macro Database** (the main program must be active) to open the database in a separate window.




Fig. 10.87

The list of the macros available on the server is in the upper left part of the window. The description of the selected macro in pdf format is displayed in the upper right part of the window. The document can be downloaded or printed. Use the button **Add to the project** to add the selected macro to the project library.

The macro added to the project library will be displayed in the lower left part of the window in the list of the project macros. The icon of the selected project macro is displayed in the lower right part of the window.

11 Display elements

Display elements are elements of the library that control the information displayed on the device display. They are available in Library Box if the workspace with a display form is active, and can be placed within a display form by drag-and-drop. The following elements are available:

- Text box
- I/O box (INT/REAL)
- I/O box (BOOL)
- Dynamic box
- Combobox

Use Property Box to customize an element.

Common parameters for all elements:

- **Coordinate X** is the position of the first (left) character placeholder of the element from the left form edge (from 0 to 15).
- **Coordinate Y** is the position of the first (left) character placeholder of the element from the upper form edge, depending on the number of the rows in the form.
- There are two options for determining the coordinates: constant (default) or variable. To use the coordinate dependent on a variable, select the coordinate and open the list on the right of the input field.
 - **Constant** – specify the coordinates in Property Box or place the element within the form by drag-and-drop.



Fig. 11.1

- **Variable** – click **Select** to select an integer variable from the list and confirm with **OK**. The display element will move according to the coordinate value controlled by the variable.
- The **Length** of the element is the number of the displayed characters (number of placeholders). The display element occupies one display row in height, its length can be changed from 1 to 16 characters maximum.

11.1 Text box

Text box is used to display constant text.

Parameters:

Text – text to be displayed. The text length may not exceed the value specified in the parameter **Length**.




Fig. 11.2




Fig. 11.3

11.2 I/O box (INT/REAL)

I/O box (INT/REAL) is used to display or change the selected variable of the type Integer or Real.




Fig. 11.4

Parameters:

Variable – the reference to a program variable. Use "... " icon to select a variable.

Data type – the data type of the variable: Integer or Real. If the variable has been already selected, its data type is applied.

Digits – the total number of the displayed characters for the variable

Decimal digits – the number of the characters after the decimal point: 0...6 characters or automatic (**Auto**). For detailed information refer to the operation manual of the device.

Text before – the text to the left of the displayed variable value

Text after – the text to the right of the displayed variable value

Editable – if **Yes**, the displayed value can be changed using the device function buttons

Note: An output variable should be referenced. The option has no effect with an input variable.

Length – the number of characters that can be displayed including the text before, the variable value and the text after

Range:

The group of parameters to control the optional restrictions on the user entered value. If **Editable = No**, the parameters of this group have no effect.

Control – if **Yes**, the value entered using the device function buttons is limited by the parameters **Max** and **Min**

Max – the maximum value for user input

Min – the minimum value for user input

Display elements

Example:




Fig. 11.5




Fig. 11.6

11.3 I/O box (BOOL)

I/O box (BOOL) is used to display or change the selected variable of the type Boolean.




Fig. 11.7

Parameters:

Variable – the reference to a program variable. Use "... " icon to select a variable.

Text TRUE – the text displayed if the referenced variable is True

Text FALSE – the text displayed if the referenced variable is False

Text before – the text to the left of the displayed variable value

Text after – the text to the right of the displayed variable value

Editable – if **Yes**, the displayed value can be changed using the device function buttons

Note: An output variable should be referenced. The option has no effect with an input variable.

Display elements

Length – the number of characters that can be displayed including the text before, the variable value and the text after




Fig. 11.8

11.4 Dynamic box

Dynamic box is used to display one of the text rows from the list depending on the value of the referenced output variable of the type Integer.




Fig. 11.9

Parameters:

Variable – the reference to a program variable. Use "..." icon to select a variable.

Row list – the table with text rows. The **Text** in the row will be displayed if the value of the referenced variable is equal to the row **ID**. The column **Characters** shows the number of characters in the text. An exclamation mark is displayed near the number if the value of the parameter **Length** is exceeded.

Length – the number of characters that can be displayed




Fig. 11.10

11.5 ComboBox

ComboBox is used to select one of the text rows from the list using the device function buttons. The ID of the row will be saved in the referenced input variable of the type Integer.




Fig. 11.11

Parameters:

Variable – the reference to a program variable. Use "... " icon to select a variable.

Row list – the table with text rows. The **Text** of the selected row is displayed and the row ID is saved in the referenced output variable. The column **Characters** shows the number of characters in the text. An exclamation mark is displayed near the number if the value of the parameter **Length** is exceeded.

Length – the number of characters that can be displayed




Fig. 11.12

12 Calibration

Only general information about calibration of analog inputs or outputs is given in this section. For detailed information about calibration refer to the user manual of the respective device.

If calibration of analog inputs or outputs is necessary, use the menu item **Device > Calibration....**

The item is active only if a device is connected. Select the target to calibrate in the opened dialog.




Fig. 12.1

If the calibration target is selected, the execution of the application on the device will be stopped. The application will be started again upon successful completion of the calibration.

12.1 Input calibration

Connect a reference signal source to the inputs to be calibrated. Select the type of signal to be connected to the input and the calibration parameters in the opened dialog.




Fig. 12.2 PR200 input calibration

Use the item **Reset settings** to apply the default settings for calibration.

Use the list **Select input** to select the input to be calibrated, click the button **Next** and follow the instructions.

12.2 Output calibration

Before calibration of an analog output, prepare the appropriate measuring device and follow the instructions. Measure the value of the signal applied to the output specified in the upper right corner of the window and enter the value into the entry field.




Fig. 12.3 PR200 output calibration

Proceed the same way with the other outputs if needed. The message about the calibration results will appear after the completion of the calibration.




Fig. 12.4

13 Program examples

Two examples with simple tasks explain the creation of a circuit program in the ALP programming software.

13.1 Task 1: Light switch with automatic switch-off

The task is to switch the light on for a certain time, e.g. for a house entry.

Task definition:

1. The light sensor F1 and the light button SB1 "TIME" are installed in front of the entrance door.
2. If the button SB1 is shortly pressed and the ambient light is insufficient, the light should be switched on for 1 minute – this time should be enough to find a key hole and to open the door.
3. If the button SB1 is pressed for 2 seconds, the light should be switched on for 3 minutes regardless of the ambient light – this mode can be useful for entrance cleaning.
4. Provide the possibility to control the light by commands from external devices or with the switch SA1 "CONST" regardless of the ambient light. This mode can be useful during the reception of guests or for further automation of the apartment as part of the "smart house" program.
5. Provide the possibility to switch on the light only at a certain time.

Device selection:

The control device must have minimum two digital inputs, one digital output and an integrated real-time clock to implement this task. These features can be provided by devices of PR110 series with the letters "RTC" in the designation.

The task implementation with the device PR110-24.8D.4R-RTC:




Fig. 13.1

Circuit program

The circuit program can be implemented in the way shown in Fig. 13.2.

Program examples




Fig. 13.2

Input I1 – connected to the light sensor F1

Input I2 – connected to the button SB1

Input I3 – connected to the switch SA1

Output Q1 – output to implement the task points 1-4

Output Q2 – output to implement the task point 5

Program description:

1. If the button SB1 is shortly pressed (< 2 s), the logical AND (D2) is enabled. If the ambient light is insufficient, the first input of D2 is also True and the timer TP "Pulse" (D3) forms a pulse with 1 minute duration. This pulse activates the output Q1 over the logical OR (D6) and the light is switched on for 1 minute.
2. If the button SB1 is pressed for > 2 s, the on-delay timer TON (D4) activates the timer TP "Pulse" (D5), a pulse with the duration of 3 minutes activates the output Q1 over logical OR (D6) and the light is switched on for 3 minutes.
3. If the ambient light is sufficient, the contact of the sensor F1 is closed, the logical AND (D2) is disabled and the timer TP "Pulse" (D3) is blocked.
4. If the switch SA1 "CONST" is closed, the output Q1 is activated over the logical OR (D6) and the light is switched on constantly.
5. If you want to use the light only on certain weekdays at certain times, you can use the output Q2. With the weekly timer CLOCKW (D7) you can set the start and the stop time and the weekdays for lighting.

The circuit program created in ALP is shown in Fig. 12.3.




Fig. 12.3

13.2 Task 2: Mixer control

The task is to implement an industrial mixer with simple control functions.

Task definition:

1. Automatic and Manual operation modes are required. The switch SA1 "MODE" is installed to switch between the modes.
2. In Automatic mode the operating cycle can be started with the button SB1 "START" and stopped automatically with the end of the cycle or manually with the button SB2 "STOP". The cycle duration is 5 minutes. During the cycle the motor of the mixer is on for 15 seconds and off for 10 seconds alternately. All settings can be changed in the program.
3. In Manual mode the motor can be started with the button SB1 "START" and stopped with the button SB2 "STOP".
4. When the motor is overloaded (overload switch F1), it should be switched off automatically, an intermittent acoustic warning signal (HA1) with the 3-second interval should be produced and an operating error should be indicated by the signal lamp HL1 "Overload".
5. The acoustic signal can be switched off with the button SB3 "RESET".
6. The button SB4 "CONTROL" is used for the functional test of the lamp HL1 and the acoustic signal HA1.

Device selection:

The control device must have minimum 6 digital inputs and 3 digital outputs to implement this task. These features can be provided by devices of PR110 series.

The task implementation with the device PR110-24.8D.4R:




Fig. 13.4

Circuit program

The circuit program can be implemented in the way shown in Fig. 13.5.




Fig. 13.5

- Input I1 – connected to the switch SA1 “MODE”
- Input I2 – connected to the button SB1 “START”
- Input I3 – connected to the button SB2 “STOP”
- Input I6 – connected to the overload switch F1
- Input I7 – connected to the button SB3 “RESET”
- Input I8 – connected to the button SB4 “TEST”
- Output Q1 – connected to the motor

Program examples

Output Q2 – connected to the acoustic signal HA1

Output Q3 – connected to the signal lamp HL1

Program description:

1. Input I2 (SB1 “START”)

If the button SB1 is pressed, the RS trigger D1 is set to True as long as there is no reset signal at the input R. Subsequent signal path depends on the state of the switch SA1 “MODE”:

- If SA1 is open (Manual mode), the logical AND (D7) and the logical OR (D8) are enabled and the motor M1 (output Q1) is switched on.
- If SA1 is closed (Automatic mode), the logical AND (D7) is disabled and the start signal can only activate the pulse generator BLINK (D5) to start the operating cycle (15 s on / 10 s off) and the on-delay timer TON (D4) to stop it (in 5 min).

2. Input I3 (SB2 “STOP”)

If the button SB2 is pressed or the switch F1 is activated, the RS trigger D1 is reset over the input R and the output Q1 is disabled.

3. Input I1 (SA1 “MODE”)

- If the switch SA1 is open (Manual mode), the logical AND D3 is disabled and D7 is enabled, the timer D4 and the pulse generator D5 are disabled and the motor M1 can be only started with SB1 and stopped with SB2.
- If the switch SA1 is closed (Automatic mode), the logical AND D3 is enabled and D7 is disabled, thus the motor M1 can be only started by the pulse generator D5 (15 s on / 10 s off cycle) and stopped by the timer D4 in 5 minutes.

4. Input I6 (overload switch F1)

When the motor is overloaded, the F1 contact is closed, the RS trigger D1 is reset and the motor is stopped.

Concurrently the signal lamp HL1 is switched on over the logical OR (D12) and the acoustic signal HA1 is activated over the RS trigger D9. The pulse generator D10 provides an intermittent acoustic signal with the cycle 3 s on / 3 s off.

5. Input I7 (SB3 “RESET”)

The button RESET is used to reset the acoustic signal HA1. If the button SB3 is pressed, the RS trigger D9 is reset and the pulse generator D10 for the acoustic signal HA1 is stopped.

6. Input I8 (SB4 “TEST”)

The button TEST is used to test the acoustic signal HA1 and the signal lamp HL1. If the button SB4 is pressed, the logical ORs D11 and D12 are enabled, the outputs Q2 and Q3 activated, the acoustic signal and the lamp are switched on.

The circuit program is shown in Fig. 13.6.




Fig. 13.6

Note:

1. The remaining two unused inputs and one output can be used for implementation of additional functions. For example, to switch between different time settings for automatic motor operation or to switch other operating parameters of the mixer.
2. The technological cycle of operation can be completely automated by implementation of an incremental counter (CT) to switch off the RS trigger D1.