

Function (programmable)	counter, RPM meter or combined
Analog Input (programmable)	0(4)...20 mA, 0...5(10) V
Input Isolation	none
Digital Inputs (CLEAR, GATE)	dry NO contact or from NPN/PNP sensor
Maximum Input Frequency	500 Hz
Sensor Supply Output	12...24 VDC, 60 mA
Relay Outputs:	up to 4
Electromechanical relay	5A/250VAC with NO/NC contact
MOS gate	0.1A/60V, optically isolated
Transistor gate	open collector NPN 40mA/40V
Output for external SSR	5...24 VDC, 30 mA
- Out1	<input type="checkbox"/> relay, <input type="checkbox"/> MOS, <input type="checkbox"/> open collector, <input type="checkbox"/> ext. SSR
- Out2	<input type="checkbox"/> relay, <input type="checkbox"/> MOS, <input type="checkbox"/> open collector, <input type="checkbox"/> ext. SSR
- Out3	<input type="checkbox"/> relay, <input type="checkbox"/> MOS, <input type="checkbox"/> open collector, <input type="checkbox"/> ext. SSR
- Out4	<input type="checkbox"/> relay, <input type="checkbox"/> MOS, <input type="checkbox"/> open collector, <input type="checkbox"/> ext. SSR
Analog Output	<input type="checkbox"/> 0...20 mA, <input type="checkbox"/> 4...20 mA, <input type="checkbox"/> 0...10 V
Power Supply	<input type="checkbox"/> 230 VAC, <input type="checkbox"/> 115 VAC, <input type="checkbox"/> 90...250 VAC/DC, <input type="checkbox"/> 24 VAC, <input type="checkbox"/> 12...24 VAC/DC
Consumption	less than 6 VA
Operating Temperature / Humidity	-10...65 °C / 0...85% RH
Protection Class: front / terminals	<input type="checkbox"/> IP65, <input type="checkbox"/> IP54 / IP20

v8-11.09

COMECO Inc., P.O.Box 378, Plovdiv 4000, BULGARIA, tel: +359 32 646523, 646524, fax: 634089
e-mail: info@comeco.org, WWW.COMECOGROUP.COM

6-DIGIT MULTIFUNCTIONAL COUNTER WITH ANALOG INPUT

CT34

OPERATION MANUAL



Please read this Operation Manual before mounting and operating!
Save the Manual for future references!

Warranty and Support

.....
serial number

.....
manufacturing date

QC check mark(passed)
(stamp)


88 Slavyanska Str.
P.O.Box 378
Plovdiv 4000, BULGARIA
tel: +359 32 646523, 646524
fax: +359 32 634089, 646517
e-mail: support@comeco.org

QD-8.2.4-WC

Warranty
COMECO warrants this product to be free from defects in materials and workmanship for 2 years. If your unit is found to be defective within that time, we will promptly repair or replace it. This warranty does not cover accidental damage, wear or tear, or consequential or incidental loss. This warranty does not cover any defects caused by wrong transportation, storage, installation, or operating (see 'Specifications').


Technical support
In the unlikely event that you encounter a problem with your COMECO device, please call your local dealer or contact directly our support team.

Modes of Operation – part III



Operation Mode 6 (Dosing Mode)
Mode = 5

- CT34 counts up and initializes at receiving CLEAR command or – when the value of **One-shot Time** is other than '0' – after the auto-restart time.
- Output Out1 activates with CLEAR command or after auto restart and stays ON until counter reaches SP1.
- With Relay Output 2 Link set to \overline{CNT} and Relay 2 Direction – to \overline{F} , output Out2 activates when SP2 is reached.



TOTAL and BATCH
As a totalizer, CT34 integrates the input to total or total batches, counted from 0 to SP1.

- To see the **TOTAL** or **BATCH**, press and hold \uparrow or \downarrow while CT34 is at Basic Level, Display Alternative 1 value is **TOTAL**, and Display Alternative 2 – **BATCH**.
- To clear the **TOTAL**, press $\overline{START/CLEAR}$ or use the CLEAR input (see 'CLEAR Functions') while holding \uparrow .
- To clear the **BATCH**, press $\overline{START/CLEAR}$ or use the CLEAR input (see 'CLEAR Functions') while holding \downarrow .

RATE (flow-rate, RPM)
CT34 can act as RMP or flow meter depending on RATE-linked parameters (see parameter table).

Displaying

- While CT34 operates at Basic level, its display readings depend on device function and respective display parameters (see parameter table).
- During programming, the upper display shows the parameter symbol and the lower – its value.
- When the counter overflows (value > 999999), CT34 displays alternatively the leftmost (starting with \overline{C}) and the rightmost value part at a 2-second interval.

Parameter Programming

Note: Changing decimal point position reflects the real value of all parameters linked to the parameter!

E.g.: changing DP Position TOTAL value from (x1) to (x0.1) would change a Set Point 1 value of 100 to 10.0!!!

Note: If the new value has not been confirmed and no key has been pressed for a certain period of time, value adjustment automatically ceases, and the parameter retains its initial value.

- Setting numerical parameter value**
- Enter parameter value adjustment mode (see 'Program Levels').
 - The whole part of the value appears on the display, and the rightmost digit blinks.
 - To increase or decrease the blinking digit value, use respectively \uparrow or \downarrow .
 - To select another digit, press \leftarrow .
 - Confirm the adjusted value with \rightarrow + \uparrow .
 - If the new value is within the limits, CT34 accepts it and goes on to the next parameter. Otherwise, the device displays the same parameter and waits for a correct value to be set.
- Setting symbolic parameter value**
- Enter parameter value adjustment mode.
 - Read the blinking parameter value.
 - To change the value, use \uparrow and \downarrow , and to confirm, press \leftarrow + \uparrow .

CT34 with analog input is a fully programmable totalizing counter / rate (RPM) meter that can be adapted to a wide variety of counting, measuring, and controlling applications. It is equipped with two 6-digit LED displays and 2 control inputs allowing 7 different operating modes. Up to 4 relays and 1 analog output may be installed, enhancing the counter to an integral part of your control application.

Mounting and Wiring

Mounting


Place CT34 into a 90x42 mm panel cut-out and tighten using the enclosed brackets.

Wiring

- Connect CT34 in accordance with the wiring diagram on the left.
- If analog output is installed instead of relay output Out2 (see 'Specifications'), wire it via terminals 7(-) and 9(+).


Important notes:

- Power supply polarity does not matter!
- Each control input may be either dry contact or electronic.
- Sensor voltage may be taken from inside or from an external source.
- If the NPN sensor does not have a resistor, add an appropriate one (1...30 kΩ)!



Analog Input Setting

- Remove the electronic block from the housing and find the configuration jumpers located on the main board.
- To set the desired analog input type (before programming), short out the respective jumper.



functions (for CNT, TOTAL, and BATCH):

- both CLEAR key and input are enabled to clear the counter
- only CLEAR input is enabled to clear the counter
- CLEAR input enables CLEAR key to clear the counter
- both CLEAR key and input are disabled

Parameter 'Clear Algorithm'

- Clear Algorithm = 0
- Clear Algorithm = 1
- Clear Algorithm = 2
- Clear Algorithm = 3

Calibrating

Note: The calibration MUST be completed for ALL input types! Once started, all calibration steps must be carried out!

- Set Calibration mode to 4E5.
- Press and hold [Enter] until t-CL displays.
- The upper display shows the calibrated input type and the lower one shows -----.
- Set jumpers for 0...10 V range.
- Simulate 0 V input.
- Confirm calibration point t-0.0 with [Enter] + [Up] or go to the next with [Up].
- Simulate 10 V input.
- Confirm t-1.0 or skip with [Up].
- Set jumpers for 0...5 V range.
- Simulate 0 V input.
- Confirm t-0.0 or go to the next.
- Simulate 5 V input.
- Confirm t-0.5 or go to the next.
- Set jumpers for mA range.
- Simulate 0 mA input.
- Confirm t-0.0 or go to the next.
- Simulate 4 mA input.
- Confirm t-0.4 or go to the next.
- Simulate 20 mA input.
- Confirm t-0.2 or go to the next.
- To exit calibration, select rtn.


Program Levels – part I

- STEP 1: Keyboard unlock
- Hold the [Enter] key pressed at power-on, and release it after Lock appears on the display.
 - Using [Up] or [Down], select EE EY and set with [Enter] + [Up].
 - To return to Basic level, select rtn and press [Enter].


Basic level
At Basic level, CT34 indicates the selected measured parameter with a resolution, according to the Point Position parameter.

- STEP 2: Configuration level
- This level contains the configuration parameters of the device.
- From Basic level, press and hold [Enter].
 - To enter Counter configuration, release the key while t-con is displayed.
 - Use [Up] or [Down] to choose a parameter (see the table on pages 6 & 7) and press [Enter] to enter the parameter value adjustment mode.
 - To return to Basic level, press [Up] + [Down] or select rtn and press [Enter].


! If no key has been pressed for 5 s, the device automatically exits Configuration level.




Modes of Operation – part II




- Operation Mode 3
Mode = 3
- CT34 counts up and initializes at receiving CLEAR command.
 - Out1 activates at SP1 and stays ON for a period set with One-shot Time or until initialization.
 - With Relay Output 2 Link set to cnt and Relay 2 Direction - to '-', output Out2 activates when SP2 is reached.



- Operation Mode 4
Mode = 4
- CT34 counts up to SP1, automatically initializes, and starts a new cycle.
 - Out1 switches ON/OFF alternatively when counter reaches SP1.
 - With Relay Output 2 Link set to cnt and Relay 2 Direction - to '-', output Out2 activates when SP2 is reached.




- Operation Mode 5
Mode = 5
- CT34 counts up to SP1, automatically initializes, and starts a new cycle.
 - Out1 activates at SP1 and stays ON for a period set with One-shot Time.
 - With Relay Output 2 Link set to cnt and Relay 2 Direction - to '-', output Out2 activates when SP2 is reached.



Operation Mode 0

Mode = 0


- ◆ CT34 counts up to SP1, stops, and initializes at receiving CLEAR command.
- ◆ Output Out1 activates when counter reaches SP1 and stays ON until initialization.
- ◆ With **Relay Output 2 Link** set to cnt and **Relay 2 Direction** – to \downarrow , output Out2 activates when SP2 is reached.



Operation Mode 1

Mode = 1


- ◆ CT34 counts up and initializes at receiving CLEAR command.
- ◆ Output Out1 activates when counter reaches SP1 and stays ON until initialization.
- ◆ With **Relay Output 2 Link** set to cnt and **Relay 2 Direction** – to \downarrow , output Out2 activates when SP2 is reached.



Operation Mode 2

Mode = 2

- ◆ CT34 counts up to SP1, stops, and initializes at receiving CLEAR command.
- ◆ Output Out1 activates at SP1 and stays ON for a period set with **One-shot Time** or until initialization (one-shot).
- ◆ With **Relay Output 2 Link** set to cnt and **Relay 2 Direction** – to \downarrow , output Out2 activates when SP2 is reached.



STEP 3: Parametric level



This level contains the control algorithm parameters. If no relay output is installed, this level does not show up.

- ◆ Enter from Basic level by pressing \blacklozenge briefly.
- ◆ Use \uparrow and \downarrow to browse the respective group of parameters (see the table on pages 6 & 7).
- ◆ To enter the displayed parameter value adjustment mode, press \blacklozenge .
- ◆ To return to Basic level, press \uparrow + \downarrow or select rtn and press \blacklozenge .

! If no key has been pressed for 20 s, the device automatically exits Parametric level.

STEP 4: Keyboard lock (if necessary)

- ◆ Hold the \blacklozenge key pressed at power-on, and release it after $LOCK$ appears on the display.
- ◆ Using \uparrow or \downarrow , select ESP or DEY (see the table overleaf) and set with \blacklozenge + \uparrow .
- ◆ To return to Basic level, select rtn and press \blacklozenge .

Parameter	Symbol	Description
Configuration Parameters (These parameters are part of Configuration level)		
Mode	t_{1_Mod}	Operating mode selection
Save	t_{1_SA}	Saves cnt value at power-off
Clear Algorithm	t_{1_cAR}	Function of CLEAR input (key)
DP Position RATE	t_{1_dPR}	RATE display decimal point position
Input Type	t_{1_nI}	Analog input signal type
Input Low	t_{1_Lo}	RATE value corresponding to LOW input range
Input High	t_{1_Hi}	RATE value corresponding to HIGH input range
Display Offset	t_{1_oFS}	Adds a constant to the measured input value
Filter Time	t_{1_FT}	Relative time constant of the input filter
Filter Band	t_{1_FB}	Action zone of the input filter
DP Position TOTAL	t_{1_dPT}	TOTAL display decimal point position
DP Position SCALE	t_{1_dPS}	SCALE display decimal point position
Scale TOTAL	t_{1_ScL}	TOTAL scaling coefficient
Time Base RATE	t_{1_tBS}	(Flow) RATE time base
Low Flow Cutoff	t_{1_coF}	Minimum flow rate limit
Linear Transformation	t_{1_Ln}	Input value transformation after measurement
One-shot Time	t_{1_oSt}	Duration of the one-shot output
Display Direction	t_{1_dDr}	Display counting direction
Display 1	t_{1_d1L}	Parameter displayed on upper display
Display 2	t_{1_d2L}	Parameter displayed on lower display
Display Alternative 1	t_{1_d1A}	Alternative parameter on upper display (press )
Display Alternative 2	t_{1_d2A}	Alternative parameter on lower display (press )
Relay Output 2 Link ⁽¹⁾	t_{1_r2L}	Defines parameter linked to Out2
Relay Output 3 Link ⁽¹⁾	t_{1_r3L}	Defines parameter linked to Out3
Relay Output 4 Link ⁽¹⁾	t_{1_r4L}	Defines parameter linked to Out4
Relay 2 Direction ⁽¹⁾	t_{1_r2d}	Control action direction of Out2
Relay 3 Direction ⁽¹⁾	t_{1_r3d}	Control action direction of Out3
Relay 4 Direction ⁽¹⁾	t_{1_r4d}	Control action direction of Out4
Calibration mode	t_{1_cAL}	Enable access to calibration mode
Parameters of the control algorithm (These parameters are part of Parametric level)		
Set Point 1 ⁽¹⁾	t_{1_SP1}	Set-point value of relay output Out1
Set Point 2 ⁽¹⁾	t_{1_SP2}	Set-point value of relay output Out2
Set Point 3 ⁽¹⁾	t_{1_SP3}	Set-point value of relay output Out3
Set Point 4 ⁽¹⁾	t_{1_SP4}	Set-point value of relay output Out4
Keyboard locking Parameter		
Keyboard Lock Mode	$LoCK$	Keyboard locking mode

⁽¹⁾ These parameters do not appear if the respective relay is not installed!

Value	Unit	Notes
0 ... 6	-	defines counter operating mode (see ' Modes of Operation ') no_YES - YES saves cnt current value in non-volatile memory
0 ... 3	-	defines CLEAR input and key (see ' CLEAR Functions ') $x1, x0.1, x0.01, x0.001$ - affects all parameters linked with RATE and with the same units $10, 4, 0.10, 0.05$ - 0...20 mA, 4...20 mA, 0...10 V, 0...5 V (see ' Analog Input Setting ') -10000 ... 10000 ISU ISU = input signal units (e.g.: l/min) -10000 ... 10000 ISU display offset 0 ... 255 - higher value for better filtration 0 ... 3000 - affects all parameters linked with TOTAL and with the same units $x1, x0.1, \dots, x0.00001$ - affects SCALE TOTAL value 0.00001 ... 9999999 - TOTAL = RATE*SCALE*DP (allows displaying TOTAL in other units) sec, min, hour, day - e.g.: l/s, t/h, m ³ /day -10000 ... 10000 ISU all values under the limit will be accepted as '0' L_n, Sqr_t - L_n - linear; Sqr_t - further square root transformation ⁽²⁾ 0 ... 3000.0 sec. for modes 2, 3, and 6 (in mode 6, value > 0 is auto-restart time) uP, d_n - uP displays from 0 to SP1; d_n displays from SP1 to 0 cnt - current count (can be zeroed/manipulated in different modes); t_{1_tE} - time passed after cnt zeroing; t_{oTAL} - total count (special zeroing only); $bAtch$ - batch count (special zeroing only); $rATE$ - (flow)rate / RPM; $..-.-, -..-.$ - $..-.-$ - relay ON over set-point; $-..-.$ - relay ON under set-point no_YES - YES enables calibration mode
-99999 ... 999999		Out1 is always linked to TOTAL and the Operation Modes
-99999 ... 999999		see Relay Output 2 Link
-99999 ... 999999		see Relay Output 3 Link
-99999 ... 999999		see Relay Output 4 Link

$EPEY, ESP, dPEY$	-	ESP - enables set-point; $EPEY$ - enables all; $dPEY$ - all locked
-------------------	---	--

⁽²⁾ If square root transformation is selected, the RATE value will be always displayed with decimal point!