

Modbus Slave / Modbus TCP Master - Converter


To obtain the complete manual please go to

www.adfweb.com/download/filefold/MN67510_ENG.pdf

To obtain the new version of this box sheet please go to

www.adfweb.com/download/filefold/BS67510-A1_ENG.pdf

CONNECTION SCHEME:



CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67510, updated at least to the version 2.000.

To obtain this software please go to

www.adfweb.com/download/filefold/SW67510.zip

ADFweb.com s.r.l.
www.adfweb.com
support@adfweb.com

Manual



Box-Sheet



Software

