


KEY FUNCTIONS




ERROR CODE OF SELF-DIAGNOSIS


- 10FL** Input signal is over 120% of input range.
- 10FL** Input signal is under -10% of input range.
- RdEr** Input signal is over 180% of input range or meter error.
- doFL** Input signal is over display range (999999).
- doFL** Input signal is under display range (-199999).
- E-00** EEPROM reading / writing suffers the interference (about 1 million times).

WIRING CONNECTION


● Voltage, Current (AC, DC)




● Temperature (RTD)




● 2 wire Transmitter




● 3 wire Transmitter



● 4 wire Transmitter or Load cell



● 2 wire Resistor



● 3 wire Potentiometer

